

You Will Need:

- Comma Neo Board
- Comma Neo Cable
- USB-C to A-Type Female Cable
- OP3/3T Phone

1. Make sure the phone is completely off, and disconnect the Ethernet cable from the port. **(Make sure the other end is either connected to your car that is turned on, or connected to a test cable that is plugged in to power.)**

2. Hold down the dfu button and continue holding it down while plugging the Ethernet cable.

3. At this point the phone should turn on. Keep holding down the dfu button as the phone boots up.

5. Once you hit the black screen, count to 20, then release the dfu button. At this point, the board will finish booting up, and should eventually boot into the vision screen.

Note: This procedure may take a few attempts before the board takes the flash.