

You Will Need:

- 12VDC Power Supply (<http://amzn.to/2s5LAAu>)
- Ethernet Cable (<http://amzn.to/2s5LJnw>)
- Small Phillips Screwdriver

1. Cut off and strip one end of ethernet cable.
2. Strip and twist the orange and blue wires together.
3. Strip and twist the orange striped and blue striped cables together.
4. Place the solid orange and blue wires in the positive (+) terminal. Screw the terminal closed.
5. Place the the striped orange and blue wires in the negative (-) terminal. Screw the terminal closed.
6. Plug in the cable to the neo device and connect to power.